

**PUT DOWN ~~THE~~  
MARKERS**

**AND NO ONE GETS HURT**

**DON'T WRITE  
ON THIS WALL UNTIL**

WRITE DATE ABOVE LINE. IMPORTANT: WIPE THOROUGHLY WITH A PAPER TOWEL BEFORE FIRST USE.



VISIT [IDEAPAIN.COM](http://IDEAPAIN.COM)  
FOR INFORMATION,  
INSPIRATION AND ➔

**HELP**

# 01

## PREP

Repair surface and sand completely smooth. Scuff glossy and non-porous surfaces with a medium grit sandpaper and wipe clean with a dry cloth. IdeaPaint will only be as smooth as the surface you paint (a skim coat may be necessary).

# 02

## PRIME

Prime surface with Kilz Premium or any vinyl acrylic primer until existing color does not show through. Let dry according to manufacturer's instructions.

# 03

## SAND

After primer dries, lightly sand with 120 grit sandpaper to remove any debris that may have collected during priming process. Wipe with a clean, dry cloth.

# 04

## VENTILATE

Open windows, doors and set HVAC system to 100% fresh air exhaust to ventilate area and prevent permeating odor.

# 05

## PROTECT

Follow all safety precautions according to the IdeaPaint Material Safety Data Sheet found on [ideapaint.com](http://ideapaint.com).

# 06

## MIX

Pour **THIS** into **THAT** and stir. **DO NOT** mix more than 2 kits at one time. Once IdeaPaint is mixed, you have **1 HOUR** to apply.

# 07

## CUT IN

IdeaPaint is applied in one coat and dries very quickly. To avoid lap marks cut in as you go and paint the surface in full verticle 2-3 feet wide sections at a time. Begin by cutting in the edges of the first section with a 4" foam roller. Use a foam brush in corners if necessary.

# 08

## COAT

Fill in the first 2-3 foot wide section using the included 9" foam roller. Back roll the section to avoid any roller marks and be sure to maintain a wet edge. Inspect each section for pinholes, speckled spots and debris as you go. Repair quickly and move on.

# 09

## REPEAT

Work your way from one end to the other. **REPEAT STEPS 7 AND 8 ON THE NEXT SECTION** until the entire surface is covered.

# 10

## WAIT

**WAIT 7 DAYS** for paint to cure. Hang the wet paint sign found on back and write in date of when it will be ready for use.

# 11

## WRITE

Once dry, it is safe to use any standard dry-erase marker on the new surface.

